

Gas Range Instructions

Instructions for Starting the Oven

1. Turn on the gas main
2. Lie on the floor so you can see the pilot through the hole
3. Switch the main control to pilot and depress.
4. Click the piezo switch, looking into the large hole above it (slightly to the left) for the pilot light to engage.
5. Once this has started, continue holding in for up to 30 seconds.
6. Now release, and change the control to use the oven as desired.

Please note:

- The stove top is simply lit with a BBQ lighter and holding in the desired switch to activate the gas (once the gas main is on).
- ***Do not forget to turn the main gas off when you are finished using the oven / stove.***



Figure 1 Examples from South Brisbane Chinese demonstrating how to lie on the floor to light the oven...